

HM2C AND HM4C CONTROL MANIFOLD OPERATING INSTRUCTIONS

Prepared by:-	M.Davies	Approved by:-	Date: 09/09/14
REV NO:-	1		
ECO:-	4282		

INTRODUCTION

Hi-Force manifolds are designed specifically to allow easy control of the direction of flow of the systems hydraulic fluid. Both the HM2C and HM4C have 3/8" NPT outlet ports. Hi-Force manifold blocks provide even greater versatility in your hydraulic system. Always specify Hi-Force manifolds for use with your Hi-Force hydraulic tools.

SAFETY NOTES


MAX WORKING PRESSURE: HM2C 700 BAR HM4C 700 BAR.

Do not exceed the max working pressure of 700 bar. Always ensure that any Hi-Force hydraulic hoses are correctly fitted to the manifold. Wear suitable personal protection equipment when operating hydraulic equipment. Keep all body parts away from cylinder and work piece / load


MANIFOLD SETUP AND OPERATION

- 1. Ensure that all ports are clean and free of debris prior to connecting any hoses. Always use PTFE or thread sealant on fittings
- 2. HM2C and HM4C manifolds feature 1 inlet port and either 2

(HM2C) or 4 (HM4C) outlet ports and either 2 (HM2C) or 4 (HM4C) needle valves. See Figure 1 **(HM2C shown with protective caps on ports).**



3 Connect hose from pump into the inlet Nipple. (Can be removed if required). See Figure 2.




Hi-Force HYDRAULIC TOOLS		HM2C AND HM4C CONTROL MANIFOLD OPERATING INSTRUCTIONS		TDS:- 1311
Prepared by:-	M.Davies	Approve	ed by:-	Date: 09/09/14
REV NO:-	1			
ECO:-	4282			


4 Connect hoses from cylinders into outlet ports.

FIGURE 4

- 5 Adjusting the knob on Needle Valve 1 will control the rate at which Hydraulic fluid exits Outlet Port
 - 1.
 - See Figure 3.



Adjusting the knob on Needle Valve 2 will control the rate at which hydraulic fluid exits Outlet Port
2.
See Figure 4.



- 7. Needle valves 1 and 2 will also restrict oil flow under reverse flow. I.e from outlet to inlet.
- 8. When fully closed the Needle Valves maybe used to prevent reverse flow in load holding applications.

WARNING: DO NOT WORK UNDER A LOAD SUPPORTED ONLY BY HYDRAULIC MEANS.

CAUTION: WHEN NEEDLE VALVES ARE CLOSED OR SLIGHTLY OPEN, WITH THE PUMP DELIVERING OIL THE PUMP PRESSURE RELIEF VALVE MAY OPERATE WHICH WILL LEAD TO THE OIL TEMPRATURE RISE AFTER EXTENDED OPERATION.



HM2C AND HM4C CONTROL MANIFOLD OPERATING INSTRUCTIONS

Prepared by:-	M.Davies	Approved by:-	Date: 09/09/14
REV NO:-	1		
ECO:-	4282		

UK Head Office:

Hi-Force Limited Prospect Way Daventry Northamptonshire NN11 8PL United Kingdom

Tel: + 44 1327 301000 Fax: + 44 1327 706555 Email: daventry@hi-force.com

Hi-Force Regional Offices:

Hi-Force Australia Pty. Ltd	Hi-Force Caspian	
Rockingham	Baku	
Australia	Azerbaijan	
Tel: +61 8 9591 1288	Tel: +994 12 447 4100	
Email: australia@hi-force.com	Email: baku@hi-force.com	
Hi-Force Hydraulics (Asia) S.B	Hi-Force Nederland BV	
Selangor	Strijen	
Malaysia	Netherlands	
Tel: +603 5569 4209	Tel: +31 78 6745488	
Email: malaysia@hi-force.com	Email: holland@hi-force.com	
Hi-Force Hydraulics (Pty) Ltd	Hi-Force FZCO	
Midrand	Dubai	
South Africa	United Arab Emirates	
Tel: +27 11 314 0555	Tel: +971 4 815 0600	
Email: south.africa@hi-force.com	Email: dubai@hi-force.com	
Hi-Force Hydraulics	Hi-Force Hydraulic Equipment	

Hi-Force Hydraulics Abu Dhabi United Arab Emirates Tel: +971 2 551 3100 Email: abu.dhabi@hi-force.com li-Force Hydraulic Equipment (Shanghai) Ltd. Co. Shanghai, China Tel: +86 21 6697 3010 Email: china@hi-force.com

GLOBAL BRAND. LOCAL

www.hi-force.com