



# PICK & CLEAN

*nitty gritty*



Scheda Tecnica  
Technical Data Sheet  
Fiche Technique

**NITTY-GRITTY SRL**  
Via dei Marmorari 36  
41057 Spilamberto (MO)  
T. 059 785210  
F. 0597861612  
VAT IT 02316620364

[www.nitty-gritty.it](http://www.nitty-gritty.it)

# PICK & CLEAN

## TECHNICAL DATA SHEET

### PICK

Soaked wipes in pickling solution for stainless steel. Ready to use. Product especially suitable for pickling TIG / MIG / electrode stainless steel welds. After use, neutralize and remove the acid residues with the CLEAN product.

#### PHISICAL AND CHEMICAL FEATURES

- Physical state : soaked wipe
- pH : 1
- Odor : strong
- Color : white wipes soaked in transparent pickling solution.

#### WARNING FOR USE



*Danger - Contains: nitric acid, ammonium bifluoride, hydrogen peroxide solution.*

Harmful if swallowed. Causes severe skin burns and eye damage. Wash with plenty of water thoroughly after handling. Wear protective gloves / protective clothing / eye protection / face protection. IF SWALLOWED: Call a POISON CENTER or doctor / physician if you feel unwell. IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. Store locked up.

#### HANDLING AND STORAGE

Adequate protective devices, such as gloves, must be worn during the use of the product in order to avoid direct contact. Keep the product in a safe place and in the original container. Do not mix it with other products.

#### EXPIRATION TIME

Product unopened: 2 years  
Once the package is opened: 4 months.

#### PACKAGING

PICK&CLEAN product is available in the following packages:

**WPEPICCLN001.06:** Carton Box containing N°6 sets, each one as following:

- N°1 Tape of PICK wipes di 4cmx25m dashed every 20cm.
- N°1 Neutralizing solution CLEAN - Bottle of 1L supplied with sprayer.

**WPEPICFMI001.06:** Carton Box (for food and medical industry) containing N°6 sets, each one as following:

- N°1 Tape of PICK wipes di 4cmx25m dashed every 20cm.
- N°1 CLEAN wipes - 125pz (15x20cm).

#### HOW TO USE

**1**



**PICK**

Apply the wipe along the weld, ensuring it adheres to the surface. Leave on for at least 10/15 minutes\*.

*\*Note: the time needed for a good pickling is a function of outside temperature and the quality of the weld.*

**2**



**CLEAN SPRAY**

Remove the PICK wipe. Spray the CLEAN solution on the worked surface to neutralize the acid residues. Dry with blotting paper.



**CLEAN WIPE**

Remove the PICK wipe and eliminate the acid residues using the neutralizing CLEAN wipe.

**NOTE:** AFTER THE PICKLING OPERATIONS, PLEASE, CLOSE THE BOXES OF THE WIPES IN ORDER TO A CORRECT CONSERVATION.

#### DISPOSAL

The disposal of special waste must be in compliance with the regulations in force.

*The information included in the Technical Data Sheet, also if representing a great knowledge about this item, are not enough for users, who must effectuate careful tests in their own works' conditions. For this reason, Nitty-Gritty disclaims all responsibility for any inappropriate product's use.*

For further information: **Nitty-Gritty S.r.l.** - ☎ : +39 059 785210 - 📠 : +39 059 7861612 - E-mail: [info@nitty-gritty.it](mailto:info@nitty-gritty.it)

### CLEAN

Neutralizing product for stainless steel. Use after pickling operations in order to remove the acid residues issued by the PICK wipes.

#### PHISICAL AND CHEMICAL FEATURES

##### CLEAN SPRAY

- Physical state : liquid
- pH : 10
- Odor : typical
- Color : semitransparent

##### CLEAN WIPES

- Physical state : soaked wipe
- pH : 10
- Odor : typical
- Color : white wipes soaked in semitransparent neutralizing solution.

#### WARNING FOR USE

The product is not classified as hazardous pursuant to the provisions set forth in Directives 67/548/EEC and 1999/45/EC Regulation 1272/2008 (CLP) and subsequent amendments and supplements.

It is suggested the use of protective gloves in order to avoid the contact with the acid residues left by the pickling operations.

#### HANDLING AND STORAGE

During the working operation it is suggested the use of protective gloves. Keep the product in a safe place and in the original container. Do not mix it with other products.

#### EXPIRATION TIME

CLEAN SPRAY : 2 years  
CLEAN WIPES : Product unopened: 2 years  
Once the package is opened: 4 months.